

#### 2012-10-5 SDMS3 Manifest Release V 2.0.1.0

### **SDMS3 V 2.0.1.0**

### Featuring:

No new feature

### Fixed:

- #3730 Does not connect with PS450
- #2960- Degree sign not displayed (Lite and non-Lite)
- #2979 Microsoft Word Export option in Current setting menu are locked depend on the View type.
- #2899 Crash when we use Save and Merge in Panels/A-Logs/BScans (precise extreme scenario).
- #3772- Change the Default directory and make sure they are set properly once the software have been installed
- #3358- Fail transfering Panel file with mode RF.
- #3329- Menu window Right click make always appear SDMS Lite.
- #3318- Cancel when we use delete All Alogs,B-scan,Panel, still delete All.

#### **Known issues:**

- #3245 Interface with Office 2010 is still problematic with Office 2010 with unknown Windows SP configuration
- #3096 A-log and Panel's name aren't correctly displayed when viewing it. Masterscan Only
- #3773- More than 104 A-Scan require more time to connect to D-20+, connection fail
- #3666- transfer Inspection Plans from PC to DFD. First one has been transferred without any problems. Each next is overwriting on this first one.

### **Minimum System Requirements**

System Processor: 300Mhz + Processor

System Memory: 512Mb Ram Recommended Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version and 64 bit)

# **Version Compatibility**

Microsoft Office: 2007 and higher

Model	Software Version
Sitescan 123W	V3.16+, V2.47+
Railscan 125	V3.16+, V2.47+
Sitescan 140	V3.16+, V2.47+
Sitescan 150	V3.16+, V2.47+
Sitescan 160	V3.16+, V2.47+
Sitescan 250	V3.16+, V2.47+
Masterscan 350	V3.16+, V2.47+
Masterscan 380	V3.16+, V2.47+
DryScan 410	V3.16+, V2.47+
Powerscan 450	V3.16+, V2.47+
Sitescan D-10	V2.2.1+ (V3.1.0 for Advanced Thickness)
Sitescan D-20	V2.2.1+ (V3.1.0 for Advanced Thickness)
Sitescan D-10+	V3.2.2+
Sitescan D-20+	V3.2.2+

# **Operating system and Tools Compatibility Matrix**



			DFD T	ools Compatibly r	natrix			
			Recommended c	onfiguration				
		VS Falcon	Win XP Win Vista		Win 7		Win 8	
Product	Product Version	Version	32	32	64	32	64	
	SDMS3 (2.0.0.2 and newer)	VS Falcon x86 (latest release)	Supported	Supported	unsupported	Supported	unsupported	unsupported
SDMS 3	SDMS3 (2.0.0.2 and newer)	VS Falcon x64 (latest release)	unsupported	unsupported	Supported	unsupported	Supported	unsupported
DFD	DFD Programmer (2.0.3 and newer)	VS Falcon x86 (latest release)	Supported	Supported	unsupported	Supported	unsupported	unsupported
Programmer	DFD Programmer (2.0.3 and newer)	VS Falcon x64 (latest release)	unsupported	unsupported	Supported	unsupported	Supported	unsupported
		End	Of Life Software					
			&					
CDNAC 2 !ub	İ	Obso	lete Configuration	1				
SDMS 3 with VS Falcon x86_old	SDMS3 (All versions)	VS Falcon	Supported*	Supported*	unsupported	unsupported	unsupported	unsupported
DFD Programmer	DFD Programmer (2.0.2 and earlier)	x86_old (November-01- 2010 and	Supported	Supported	unsupported	unsupported	unsupported	unsupported
SDMS 2 with VS Falcon x86 old	•		Supported	Supported	unsupported	unsupported	unsupported	unsupported

<sup>\*</sup>Not recommended configuration because several fixes to VS Falcon are incorporated



#### 2012-10-5 SDMS3 Manifest Release V 2.0.0.9

### **SDMS3 V 2.0.0.9**

### Featuring:

No new feature

#### Fixed:

- #3730 Does not connect with PS450
- #3314 Wrong value for of particular settings of the panel when transferring file from unit to SDMS3.
- #3278 Gain's value take Ref Gain value instead of Gain value when reload file.
- #3254 AVG curve disappears when transferring a second time.
- #3107 Incorrect probe FREQUENCY transferred from SDMS Lite & SDMS3 to Word
- #3035 When a stored B-Log is viewed in SDMS3, the view appear visible when you first click on the thickness box but disappears when click afterward
- #3034 Using Falcon (380 and 250S) with both versions of SDMS3 does not show probe zero (always at 0)
- #3028 Quick Download feature shoud not be available when there are only empty file on DFD memory.
- #3012 Export to Excel corrections
- #3011 A-scan thickness logging signal show -6db less amplitude than on the D-series.
- #3001 Warning message that our Data file in our PC memory will be erased when using the option Current Settings>Grab.
- #2999 FREQUENCY transferred with value a "BEL" shown in Calibration menu in SDMS and probe frequency changed
  to first value for all Panels when uploaded back into DFD. "
- #2995 IO connector error when pressing two time connect.
- #2966 Occasionally it stated "unable to create document" but OK on a second attempt.
- #2965 Corruption of AVG curves and GAIN over transfer with MS380 (SDMS3 Non-Lite)
- #2961 AVG curve not restored in D-20+ but showing in SDMS view (on D-Series).
- #2941 When loading a inspection Plan with a B-scan stored, we can see the B-scan views only in the cell #4.
- #2936 Unhandled exception when Open Workbook in Inspection Plans.
- #2887 Unhandled exception when we creating a inspection plan after that we open a empty excel file with open Workbook.
- #3329 Menu window Right click make always appear SDMS Lite
- #3318 Cancel when we use delete All Alogs, B-scan, Panel, still delete All

# **Known issues:**

- #3245 Interface with Office 2010 is still problematic with Office 2010 with unknown Windows SP configuration
- #3096 A-log and Panel's name aren't correctly displayed when viewing it. Masterscan Only
- #2899 Crash when we use Save and Merge in Panels/A-Logs/BScans (precise extreme scenario).
- #2979 Microsoft Word Export option in Current setting menu are locked depend on the View type.

# **Minimum System Requirements**

System Processor: 300Mhz + Processor
System Memory: 512Mb Ram Recommended
Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version and 64 bit)

#### **Version Compatibility**

Microsoft Office: 2003 and higher



Model	Software Version
Sitescan 123W	V3.16+, V2.47+
Railscan 125	V3.16+, V2.47+
Sitescan 140	V3.16+, V2.47+
Sitescan 150	V3.16+, V2.47+
Sitescan 160	V3.16+, V2.47+
Sitescan 250	V3.16+, V2.47+
Masterscan 350	V3.16+, V2.47+
Masterscan 380	V3.16+, V2.47+
DryScan 410	V3.16+, V2.47+
Powerscan 450	V3.16+, V2.47+
Sitescan D-10	V2.2.1+ (V3.1.0 for Advanced Thickness)
Sitescan D-20	V2.2.1+ (V3.1.0 for Advanced Thickness)
Sitescan D-10+	V3.2.2+
Sitescan D-20+	V3.2.2+

# Operating system and Tools Compatibility Matrix

DFD Tools Compatibly matrix								
Recommended configuration								
	Product	VS Falcon	Win XP	Win	Vista	ista Win 7		
Product	Version	Version	32	32	64	32	64	
SDMS 3	SDMS3 (2.0.0.2 and newer)	VS Falcon x86 (latest release)	Supported	Supported	unsupported	Supported	unsupported	
	SDMS3 (2.0.0.2 and newer)	VS Falcon x64 (latest release)	unsupported	unsupported	Supported	unsupported	Supported	
DFD	DFD Programmer (2.0.3 and newer)	VS Falcon x86 (latest release)	Supported	Supported	unsupported	Supported	unsupported	
Programmer	DFD Programmer (2.0.3 and newer)	VS Falcon x64 (latest release)	unsupported	unsupported	Supported	unsupported	Supported	
End Of Life Software & Obsolete Configuration								
SDMS 3 with VS Falcon x86_old	SDMS3 (All versions)		Supported*	Supported*	unsupported	unsupported	unsupported	
DFD Programmer	DFD VS Falcon DFD Programmer x86_old Programmer (2.0.2 and (November-	x86_old (November- 01-2010 and	Supported	Supported	unsupported	unsupported	unsupported	
SDMS 2 with VS Falcon x86_old	All version	earlier)	Supported	Supported	unsupported	unsupported	unsupported	

<sup>\*</sup>Not recommended configuration because several fixes to VS Falcon are incorporated



# 2012-04-18 SDMS3 Manifest Release V 2.0.0.8

Not applicable, only released in Beta. To avoid any confusion the official release have been released on 2.0.0.9



#### 2011-12-01 SDMS3 Manifest Release V 2.0.0.7

### **SDMS3 V 2.0.0.7**

# Featuring:

No new feature

### Fixed:

- Issue #3000 Downloading of numeric thickness measurements on MasterScan has been re-enabled
- Issue #2897 Transfer Empty file is not allowed
- Issue #2959 LOCATION shall be displayed BLOCK (Lite and non-Lite)
- Issue #2895 Using Delete All B-scans and Alogs doesn't refresh the views in DFD views.
- Issue #2902 -Warning message when deleting ALL A-Logs, Panel Files or BScans.

#### **Known issues:**

- 1. Issue #2897 Degree sign not displayed (Lite and non-Lite) (DFD issue)
- 2. Issue #2934 Frequency and some others transferred with value "BEL" (on D-Series).
- 3. Issue #2935 Change interface font color doesn't work.
- 4. Issue #2887 Unhandled exception creating Inspection plan.
- 5. Issue #2965 Corruption of AVG Curves and Gain over transfer with MS380.
- 6. When transferring many A-log file with different name from PC to DFD, those files are named all the same as the last file transferred.
- 7. Issue #3001 Warning message that our Data file in our PC memory will be erased when using the option Current Settings->Grab.

### **Minimum System Requirements**

System Processor: 300Mhz + Processor

System Memory: 512Mb Ram Recommended

Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version and 64 bit)

# **Version Compatibility**

Microsoft Office: 2003 and higher

Model	Software Version
Sitescan 123W	V3.16+, V2.47+
Railscan 125	V3.16+, V2.47+
Sitescan 140	V3.16+, V2.47+
Sitescan 150	V3.16+, V2.47+
Sitescan 160	V3.16+, V2.47+
Sitescan 250	V3.16+, V2.47+
Masterscan 350	V3.16+, V2.47+
Masterscan 380	V3.16+, V2.47+
DryScan 410	V3.16+, V2.47+
Powerscan 450	V3.16+, V2.47+
Sitescan D-10	V2.2.1+ (V3.1.0 for Advanced Thickness)
Sitescan D-20	V2.2.1+ (V3.1.0 for Advanced Thickness)
Sitescan D-10+	V3.2.2+
Sitescan D-20+	V3.2.2+



### 2011-12-01 SDMS3 Manifest Release V 2.0.0.6

### SDMS3 V 2.0.0.6

# Featuring:

### Fixed:

- Issue Tickness Logging.
- Issue #2897 Transfer Empty file.

#### **Known issues:**

- 1. Issue #2934 Frequency and some others transferred with value "BEL".
- 2. Issue #2935 Change interface font color doesn't work.
- 3. Issue #2893 Error code: 3008, Error Reading File data 0.
- 4. Issue #2887 Unhandled exception creating Inspection plan.
- 5. Issue #2937 Unable to create Word, appears twice.
- 6. Issue #2965 Corruption of AVG Curves and Gain over transfer with MS380.

# **Minimum System Requirements**

System Processor: 300Mhz + Processor

System Memory: 512Mb Ram Recommended

Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version and 64 bit)

#### **Version Compatibility**

Microsoft Office: Higher than 2003

SDMS3 Software Ver 1.0.0

Model Software Version

Sitescan 123W V3.16+, V2.47+ Railscan 125 V3.16+, V2.47+ Sitescan 140 V3.16+, V2.47+ Sitescan 150 V3.16+, V2.47+ V3.16+, V2.47+ Sitescan 160 Sitescan 250 V3.16+, V2.47+ Masterscan 350 V3.16+, V2.47+ V3.16+, V2.47+ Masterscan 380 V3.16+, V2.47+ DryScan 410 Powerscan 450 V3.16+, V2.47+

Sitescan D-10 V2.2.1+ (V3.1.0 for Advanced Thickness) Sitescan D-20 V2.2.1+ (V3.1.0 for Advanced Thickness)



#### 2011-09-15 SDMS3 Manifest Release V 2.0.0.5

### **SDMS3 V 2.0.0.5**

# Featuring:

# Fixed:

- Issue Tickness Logging.
- Issue #168 Transfer all Alog File" from PC memory to DFD memory, delete the first file from Panels in DFD memory, cannot recover, occurs 1/1

# **Known issues:**

- 7. Issue #2960 Degree sign not displayed.
- 8. Issue #2897 Transfer empty file.
- 9. Issue #2934 Frequency and some others transferred with value "BEL".
- 10. Issue #2887 Unhandled exception creating Inspection plan.
- 11. Issue #2937 Unable to create Word, appears twice.

### **Minimum System Requirements**

System Processor: 300Mhz + Processor

System Memory: 512Mb Ram Recommended

Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version and 64 bit)

# **Version Compatibility**

Microsoft Office: Higher than 2003

SDMS3 Software Ver 1.0.0

Model Software Version

V3.16+, V2.47+ Sitescan 123W Railscan 125 V3.16+, V2.47+ Sitescan 140 V3.16+, V2.47+ Sitescan 150 V3.16+, V2.47+ Sitescan 160 V3.16+, V2.47+ Sitescan 250 V3.16+, V2.47+ Masterscan 350 V3.16+, V2.47+ Masterscan 380 V3.16+, V2.47+ DryScan 410 V3.16+, V2.47+ V3.16+, V2.47+ Powerscan 450

Sitescan D-10 V2.2.1+ (V3.1.0 for Advanced Thickness)
Sitescan D-20 V2.2.1+ (V3.1.0 for Advanced Thickness)



#### 2010-06-01 SDMS3 Manifest Release V 2.0.0.4

### SDMS3 V 2.0.0.4

# Featuring:

- Russian Language Support
- Support for Updated Falcon USB Driver

#### Fixed:

- Issue #180 Unrecognised file and File ID incorrect message when opening a excel file with Map Data.
- Issue #170 Crash when Create Document in menu Panels/A-Logs/Bscans.
- Issue#165 Unplug DFD error.

#### **Known issues:**

- 12. Issue Tickness logging.
- 13. Issue #168 Transfer all Alog File" from PC memory to DFD memory, delete the first file from Panels in DFD memory, cannot recover, occurs 1/1
- 14. Issue #2897 Transfer empty file.
- 1. Issue #2887 Unhandled exception creating Inspection plan.
- 2. Issue #2937 Unable to create Word, appears twice.

# **Minimum System Requirements**

System Processor: 300Mhz + Processor

System Memory: 512Mb Ram Recommended

Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version and 64 bit)

# **Version Compatibility**

Microsoft Office: Higher than 2003

SDMS3 Software Ver 1.0.0

Model Software Version

Sitescan 123W V3.16+, V2.47+ Railscan 125 V3.16+, V2.47+ Sitescan 140 V3.16+, V2.47+ V3.16+, V2.47+ Sitescan 150 Sitescan 160 V3.16+, V2.47+ V3.16+, V2.47+ Sitescan 250 Masterscan 350 V3.16+, V2.47+ Masterscan 380 V3.16+, V2.47+ DryScan 410 V3.16+, V2.47+ Powerscan 450 V3.16+, V2.47+

Sitescan D-10 V2.2.1+ (V3.1.0 for Advanced Thickness) Sitescan D-20 V2.2.1+ (V3.1.0 for Advanced Thickness)



#### 2011-05-24 SDMS3 Manifest Release V 2.0.0.3

### **SDMS3 V 2.0.0.3**

# Featuring:

# Fixed:

• Issue #177: Unhandled exception when Save Plan after doing this procedure.

### **Known issues:**

- 1. Issue #170 Crash when Create Document in menu Panels/A-Logs/Bscans
- 2. Issue #2897 Transfer empty file.
- 3. Issue #180 Unrecognised file and File ID incorrect message when opening a excel file with Map Data.

### **Minimum System Requirements**

System Processor: 300Mhz + Processor

System Memory: 512Mb Ram Recommended

Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version and 64 bit)

### **Version Compatibility**

Microsoft Office: Higher than 2003

SDMS3 Software Ver 1.0.0

Model Software Version

Sitescan 123W V3.16+, V2.47+ Railscan 125 V3.16+, V2.47+ V3.16+, V2.47+ Sitescan 140 V3.16+, V2.47+ Sitescan 150 V3.16+, V2.47+ Sitescan 160 Sitescan 250 V3.16+, V2.47+ Masterscan 350 V3.16+, V2.47+ Masterscan 380 V3.16+, V2.47+ DryScan 410 V3.16+, V2.47+ Powerscan 450 V3.16+, V2.47+

Sitescan D-10 V2.2.1+ (V3.1.0 for Advanced Thickness) Sitescan D-20 V2.2.1+ (V3.1.0 for Advanced Thickness)



### 2011-01-13 SDMS3 Manifest Release V 2.0.0.2

# SDMS3 V 2.0.0.2

# Featuring:

• Support for Windows 64-Bit Opperating Systems with New USB Driver

### Fixed:

•

### **Known issues:**

4. Issue #170 – Crash when Create Document in menu Panels/A-Logs/Bscans

# **Minimum System Requirements**

System Processor: 300Mhz + Processor

System Memory: 512Mb Ram Recommended

Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version and 64 bit)

# **Version Compatibility**

Microsoft Office: Higher than 2003

SDMS3 Software Ver 1.0.0

Model Software Version

Sitescan 123W V3.16+, V2.47+ Railscan 125 V3.16+, V2.47+ Sitescan 140 V3.16+, V2.47+ Sitescan 150 V3.16+, V2.47+ Sitescan 160 V3.16+, V2.47+ Sitescan 250 V3.16+, V2.47+ Masterscan 350 V3.16+, V2.47+ Masterscan 380 V3.16+, V2.47+ DryScan 410 V3.16+, V2.47+ Powerscan 450 V3.16+, V2.47+

Sitescan D-10 V2.2.1+ (V3.1.0 for Advanced Thickness)
Sitescan D-20 V2.2.1+ (V3.1.0 for Advanced Thickness)



#### 2010-03-29 SDMS3 Manifest Release V 1.0.0.0

### **SDMS3 V 1.0.0.0**

# Featuring:

- All new User Interface
- D-Series Advanced Thickness Support (inc Sequence Text and Custom Label Sets)
- Split and Active View Included.
- Masterscan & D-Series (SW Version < 3.0.0) Thickness Download Supported.
- B-Log Support
- Direct word Export of A-Log, Panels and B-log

# Fixed:

• Original Version

# **Known issues:**

- Temperature Compensation functions not supported
- AVG in Masterscan Series Not Supported
- Super-imposed A-Logs not supported
- Internationalisation interface not supported.

# **Minimum System Requirements**

System Processor: 300Mhz + Processor

System Memory: 512Mb Ram Recommended

Free Disk Space: 40Mb of Free Disk Space

Operating System: Windows XP, Vista or Windows 7 (32-Bit Version only)

# **Version Compatibility**

Microsoft Office: Higher than 2003

SDMS3 Software Ver 1.0.0

Model Software Version

Sitescan 123W V3.16+, V2.47+

Railscan 125 V3.16+, V2.47+

Sitescan 140 V3.16+, V2.47+

Sitescan 150 V3.16+, V2.47+

Sitescan 160 V3.16+, V2.47+

Sitescan 250 V3.16+, V2.47+

Masterscan 350 V3.16+, V2.47+

Masterscan 380 V3.16+, V2.47+

DryScan 410 V3.16+, V2.47+

Powerscan 450 V3.16+, V2.47+

Sitescan D-10 V2.2.1+ (V3.1.0 for Advanced Thickness)

Sitescan D-20 V2.2.1+ (V3.1.0 for Advanced Thick