

VEO+ Public Manifest

VEO+ 3.11

Important Application Notice

None

Improvements

2016-06-22 VEO+ Release 3.11.6

- 178 New software option for PA-CSC
- 440 New example files for PA-CSC
- 1671 New UTDATA, UTCFG, PDF, IMAGE icons
- 1543 Auto TCG sweep with skips
- 701 Add WiFi IP adress in About Windows
- 1799 New layout implementation
- 579 Now default weld angle value is 30° (used to be 45°)
- 1416 Wedge PA angle auto-calibration wizard
- 1448 Review of calibration breakers relations
- 57 If USB unplug it now deletes recent files link
- 1627 Change Radius for Diameter
- 1684 Add IFT culling option in the beginning of TCG/DAC Wizard
- 1738 Replace "New Inspection Wizard" by "Create New Configuration"

- Fix 638 Code doesn't accept mono refracted at angle 90°
- Fix 1798 Cross Hair cursor doesn't show the measurement at its intersection in many views
- Fix 322 F3 reset shortcut doesn't work when 2D quadrature encoded and Timed Base
- Fix 609 Screen brightness parameter missing for Veo's
- Fix 629 DGS Wizard Ends too fast
- Fix 1615 Welcome screen - battery indicators are cut off
- Fix 1439 AQR indicator mis-behavior with 2 TOFD scans
- Fix 1630 Going back in wizard replaces value to default

Known Issues in VEO+ Release 3.11

- 32 File loaded from USB key cannot be saved after removing the key.
- 40 Maximizing Merged C-scan view clears the view.
- 565 3D views improvement for P&C functionalities.
- 635 WiFi refresh button in configuration screen not working. - WA turn OFF/ON the antenna.
- 601 WiFi right password isn't recognize correctly after reboot - WA re-enter password.
- 363 Wheel touch doesn't work while in velocity wizard - WA use arrows
- 280 Measures in Part References don't consider Encoding Area offset+rotation
- 263 Reset all in Time-based should reset all data - WA make a manual reset
- 236 Sometimes split DAC vertical lines are not drawn
- 231 Redundant info in 3D view or wrong abbreviation used for focal distance
- 32 File loaded from USB key cannot be saved after removing the key
- 406 Cross Hair Cursor doesn't move in S-Scan when moving the Mouse Cursor

VEO+ 3.10

Important Application Notice

None

Improvements

2016-05-02 VEO+ Release 3.10.11

Fix 90 Error in FL calculation - Beam exit point outside wedge

2016-04-21 VEO+ Release 3.10.10

1476 Update for multiple OS security fixes.

1584 New layout for 5 Scan that includes a B-Scan.

Fix 1397 Mono DAC interface.

Fix 1490 UT function noise.

2016-03-15 VEO+ Release 3.10.8

First public release.

Known Issues in VEO+ Release 3.10

32 File loaded from USB key cannot be saved after removing the key.

40 Maximizing Merged C-scan view clears the view.

565 3D views improvement for P&C functionalities.

609 Screen brightness parameter missing.

635 WiFi refresh button in configuration screen not working. - WA turn OFF/ON the antenna.

601 WiFi right password isn't recognize correctly after reboot - WA re-enter password.

592 Auto FSH in DGS wizard not accurate - WA make manual adjustment.

363 Wheel touch doesn't work while in velocity wizard - WA use arrows.

322 F3 reset shortcut doesn't work when 2D quadrature encoded - WA manual reset.

280 Measures in Part References don't consider Encoding Area offset+rotation.

263 Reset all in Time-based should reset all data - WA manual reset.

236 Sometimes split DAC vertical lines are not drawn.

231 Redundant info in 3D view or wrong abbreviation used for focal distance.

1439 AQR indicator unexpected behavior when having 2 TOFD scans.

1541 Part Thickness and geometry index offset breaks calibration