

# Veo+ Public Manifest

May 4, 2017

## **2017-05-05 Veo+ 3.17.11**

### **New Features**

- 378** Configuration Report according to ASME/API/AWS standards
- 691** Optimized features for Pitch & Catch configuration with Phased Array
- 701** New Reload TCG/DAC curve feature when breaking calibration
- 751** New Option to hide documentation for training purposes

### **Fixed Issues**

- 512** System asked to save file when pressing shutdown button
- 740** Compatibility issues with files created in version 3.8.2 or earlier
- 799** Fix SDH wedge delay wizard on sectorial scan
- 801** Cursors info missing from expanded reports

### **Known Issues**

- 585** Issues when zooming on views with keyboard
- 708** Issues converting TCG to DAC with angulated wedge

## **2017-04-20 Veo+ 3.16.2**

### **New Features**

- 738** New Automatic Reset of Scan Axis for Circular parts
- 758** New Scrolling Merged C-scan in encoded view

### **Fixed Issues**

- 744** Fix High Resolution problems on long scan axis

### **Known Issues**

- 448** Windows requests to scan USB after every use with instrument
- 585** Issues when zooming on views with keyboard
- 708** Issues converting TCG to DAC with angulated wedge

## **2017-03-21 Veo+ 3.15.4**

### **New Features**

**735** Updated Translation for all languages

**434** New Scrolling C-scan in encoded view

**045** New Cloud Remote access solutions powered by LogMeIn Hamachi

### **Fixed Issues**

**749** Add BIOS programming support for new veo+ COM modules

**586** Fix overlapped tabs when using Japanese language

**029** Cartesian cursor not showing true depth measurement

**199** Data is not erased when using invert scan direction

**489** DGS curve disappearing on load configuration

**592** Crash on save view data to .csv

**640** Crash on load .utdata file with Russian language activated

### **Known Issues**

**448** Windows requests to scan USB after every use with instrument

**585** Issues when zooming on views with keyboard

**740** Compatibility issues with files created in version 3.8.2 or earlier

## **2017-01-26 Veo+ 3.14.3**

### **New Features**

**2272** Prod Tools & Service Centers Improvements

**568** Improved WiFi functionalities

### **Fixed Issues**

**2294** TCG Calibration breaking when dB ref is changed

**2604** System switches from russian to english at reboot

**601** After Reboot, WiFi password is not recognized

**616** Cannot rename folder after moving/copying file into it

**1704** Rescue process to factory default cannot be completed properly

**1883** Element activation wizard for a scan cancels calibration of other scans

## **2016-10-25 Veo+ 3.13.3**

### **New Features**

None

### **Fixed Issues**

**2165** TOFD Gate measurements improvement

## Known Issues

- 32 File loaded from USB key cannot be saved after removing the key
- 40 Maximizing Merged C-scan view during acquisition clears the view
- 635 WiFi refresh button in configuration screen not working. - WA turn OFF/ON the antenna
- 363 Wheel touch doesn't work while in velocity wizard - WA use arrows
- 236 In some occasion a split DAC vertical lines is not drawn - WA re-implement the DAC
- 231 Redundant info in 3D view or wrong abbreviation used for focal distance

## 2016-09-16 Veo+ 3.12.7

### New Features

- 1575 New automatic filenaming functionality
- 1697 New ezDGS functionalities: curve importation from GE probe (single & twin crystal probes)
- 1569 New PA natural focal mode (no-focusing)
- 1715 New default FTP user name = ftpuser
- 1716 New default VNC password = password
- 2005 New UI language update: Japanese + updates on other languages
- 1922 Preferred recording drive is SSD for fast record of large files
- 1952 Integrated wedge is now part of the wedge advanced parameters (yes/no)
- 2087 DAC to TCG is now available in SCAN menu (stop mode)

### Fixed Issues

- 263 Reset all in Time-based should reset all data
- 601 WiFi right password isn't recognize correctly after reboot
- 406 Cross Hair Cursor doesn't move in S-Scan when moving the Mouse Cursor
- 642 Change the default value for Elmt Diameter of a mono circular probe
- 779 Overlapped UI tabs in Hungarian, German, Japanese, Slovak
- 1838 Change weld on curved surface with constant path focus breaks calibs
- 2025 We not supposed change dB during recording
- 2079 TCG curve cannot be edited after modifying the gain
- 2081 Error when adding a second scan on curved surface

### Known Issues

- 32 File loaded from USB key cannot be saved after removing the key
- 40 Maximizing Merged C-scan view during acquisition clears the view
- 635 WiFi refresh button in configuration screen not working. - WA turn OFF/ON the antenna
- 363 Wheel touch doesn't work while in velocity wizard - WA use arrows
- 236 In some occasion a split DAC vertical lines is not drawn - WA re-implement the DAC
- 231 Redundant info in 3D view or wrong abbreviation used for focal distance

## 2016-06-22 Veo+ 3.11.6

### New Features

- 178 New software option for PA-CSC
- 440 New example files for PA-CSC
- 1671 New UTDATA, UTCFG, PDF, IMAGE icons
- 1543 Auto TCG sweep with skips
- 701 Add WiFi IP adress in About Windows
- 1799 New layout implementation
- 579 Now default weld angle value is 30° (used to be 45°)
- 1416 Wedge PA angle auto-calibration wizard
- 1448 Review of calibration breakers relations
- 57 If USB unplug it now deletes recent files link
- 1627 Change Radius for Diameter
- 1684 Add IFT culling option in the beginning of TCG/DAC Wizard
- 1738 Replace "New Inspection Wizard" by "Create New Configuration"

### Fixed Issues

- 638 Code doesn't accept mono refracted at angle 90°
- 1798 Cross Hair cursor doesn't show the measurement at its intersection in many views
- 322 F3 reset shortcut doesn't work when 2D quadrature encoded and Timed Base
- 609 Screen brightness parameter missing for Veo's
- 629 DGS Wizard Ends too fast
- 1615 Welcome screen - battery indicators are cut off
- 1439 AQR indicator mis-behavior with 2 TOFD scans
- 1630 Going back in wizard replaces value to default

### Known Issues

- 32 File loaded from USB key cannot be saved after removing the key.
- 40 Maximizing Merged C-scan view clears the view.
- 565 3D views improvement for P&C functionalities.
- 635 WiFi refresh button in configuration screen not working. - WA turn OFF/ON the antenna.
- 601 WiFi right password isn't recognize correctly after reboot - WA re-enter password.
- 363 Wheel touch doesn't work while in velocity wizard - WA use arrows
- 280 Measures in Part References don't consider Encoding Area offset+rotation
- 263 Reset all in Time-based should reset all data - WA make a manual reset
- 236 Sometimes split DAC vertical lines are not drawn
- 231 Redundant info in 3D view or wrong abbreviation used for focal distance
- 406 Cross Hair Cursor doesn't move in S-Scan when moving the Mouse Cursor

## 2016-05-02 Veo+ 3.10.11

### New Features

None

### Fixed Issues

**90** Error in FL calculation - Beam exit point outside wedge

## 2016-04-21 Veo+ Release 3.10.10

### New Features

**1476** Update for multiple OS security fixes.

**1584** New layout for 5 Scan that includes a B-Scan.

### Fixed Issues

**1397** Mono DAC interface.

**1490** UT function noise.

## 2016-03-15 Veo+ 3.10.8

*First public release.*

### Known Issues

**32** File loaded from USB key cannot be saved after removing the key.

**40** Maximizing Merged C-scan view clears the view.

**565** 3D views improvement for P&C functionalities.

**609** Screen brightness parameter missing.

**635** WiFi refresh button in configuration screen not working. - WA turn OFF/ON the antenna.

**601** WiFi right password isn't recognize correctly after reboot - WA re-enter password.

**592** Auto FSH in DGS wizard not accurate - WA make manual adjustment.

**363** Wheel touch doesn't work while in velocity wizard - WA use arrows.

**322** F3 reset shortcut doesn't work when 2D quadrature encoded - WA manual reset.

**280** Measures in Part References don't consider Encoding Area offset+rotation.

**263** Reset all in Time-based should reset all data - WA manual reset.

**236** Sometimes split DAC vertical lines are not drawn.

**231** Redundant info in 3D view or wrong abbreviation used for focal distance.

**1439** AQR indicator unexpected behavior when having 2 TOFD scans.

**1541** Part Thickness and geometry index offset breaks calibration